

Алматы (7273)495-231
 Ангартс (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://roaster.nt-rt.ru> || res@nt-rt.ru

ROASTER AND ROASTER



INVERTER DRIVEN MOTORS

It protects the motors in case of any abnormally and let consume less energy. Plug in single phase and run 3 phase motors, silent run to listen only cracks. Inverter for longer life motors.



AIRFLOW CONTROL

Airflow can be increased or decreased during roasting process manually in case of need. You can control the profile's airflow parameter to reach desired taste.

R&R Roaster and Roaster machines are proudly handcrafted by our team in Turkey.



4 MOTOR ROASTER

R10 10kg batch capacity coffee roasting machine can perform roasts simultaneously with cooling. Drum, Exhaust Fan, Cooling Mixer and Cooling Fan have separate motors.

STANDARD FRATURES AND EQUIPMENTS

- Sampling spoon and sight window
- 10kg batch capacity
- Drum and Exhaust temperature indicator and controller
- Chaff collector
- Simultaneous roasting and cooling
- Faster cooling with strong cooler fan



ARTISAN, HIGH-END COFFEE ROASTING MACHINES

R&R

ROASTER AND ROASTER

GAS CONTROL

Burners are controlled by electronic ignition and burning system. Single push enough to start burner. In case of any abnormally on gas it stops the burner and gas for safety. Reset button helps for re-start the burner. CE certified control cards are equipped with compatible gas valves.



FLAME CONTROL

Shoproasters Flame height can be adjusted manually by Flame Adjusting knob on body. You can reduce or increase the flame height at any time of roasting process. It helps for heating power control of roasting to reach profile you targeted. Vapporize the chlorogenic acids and get the flavor. R&R Roaster and Roaster produces Artisan Coffee Roasting machines for artisan rosteries.

TECHNICAL SPECIFICATION

Batch Capacity	: 10 kg
Roasting Period	: 11-15 minutes
Dimensions	: 140 x 190 x 172 cm
Weight	: 400 kg
Voltage	: 110 / 220 / 380 V
Frequency	: 50 – 60 hz
Fuel	: Gas (LPG, Propane, Natural Gas)
Number of Motors	: 4 pcs, Drum, Mixer, Exhaust Fan,
Mixer Fan	



Audible Warning	: Audible warning when it reaches to set drum temperatures
Electrical Parts	: R&R use most common and famous brand electrical parts on machines
Safety	: We prefer CE certified parts and components on production.
Quiet Run	: Quiet run helps to hear first crack and second crack clearly by inverter driven motors




R&R coffee roasters control boards have 2 options; manuel control and touch screen PLC control. Manuel control comes with sepearate start stop buttons of each motor, burner switch and emergency stop buttons. 2 thermostat with indicators for drum and exhaust temperature.

Touch screen PLC control roasters have software developed by our R&D team to control and save drum speed, airflow, temperature. Operator can save the recipes and recall them while roasting.



FLAME SIGHT WINDOW

Flame height can be observed by sight window on front face.



R&R Roaster and Roaster machines are proudly handcrafted by our team in Turkey.

Алматы (7273)495-231	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Ростов-на-Дону (863)308-18-15	Тольятти (8482)63-91-07
Ангарск (3955)60-70-56	Ижевск (3412)26-03-58	Москва (495)268-04-70	Рязань (4912)46-61-64	Томск (3822)98-41-53
Архангельск (8182)63-90-72	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Самара (846)206-03-16	Тула (4872)33-79-87
Астрахань (8512)99-46-04	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Севастополь (8692)22-31-93	Улан-Удэ (3012)59-97-51
Благовещенск (4162)22-76-07	Кемерово (3842)65-04-62	Ноябрьск (3496)41-32-12	Саранск (8342)22-96-24	Уфа (347)229-48-12
Брянск (4832)59-03-52	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Владивосток (423)249-28-31	Коломна (4966)23-41-49	Омск (3812)21-46-40	Смоленск (4812)29-41-54	Чебоксары (8352)28-53-07
Владикавказ (8672)28-90-48	Кострома (4942)77-07-48	Орел (4862)44-53-42	Сочи (862)225-72-31	Челябинск (351)202-03-61
Владимир (4922)49-43-18	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Ставрополь (8652)20-65-13	Череповец (8202)49-02-64
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Сургут (3462)77-98-35	Чита (3022)38-34-83
Вологда (8172)26-41-59	Курск (4712)77-13-04	Петрозаводск (8142)55-98-37	Сыктывкар (8212)25-95-17	Якутск (4112)23-90-97
Воронеж (473)204-51-73	Курган (3522)50-90-47	Псков (8112)59-10-37	Тамбов (4752)50-40-97	Ярославль (4852)69-52-93
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пермь (342)205-81-47	Тверь (4822)63-31-35	

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://roaster.nt-rt.ru> || res@nt-rt.ru